
1 Brake
OFF
ON
2 Battery Type
Li-xx
Ni-xx
3 Cut Off Type
Soft-Cut
Cut-Off
4 Cut Off Voltage
Low
Middle
High
5 Start Mode
Normal
Soft
Very Soft
6 Timing Mode
Low
Middle
High
7 Music
Li-Po Cells
D
C
B
A
8 Governor Mode
OFF
ON
Connecting
BEC
Load Default
OK